

Volkswagen Toureg Extender Installation Guide

Thank You

Thank you for ordering brackets from ExtendMySeat, the automotive solution for more leg-room, more comfort and better driving.

Inventory in Box:

- 2 ExtendMySeat brackets
- 4 Black 3/8 bolts

What you will need for assembly:

- 1 Socket wrench
- 1 Metric 16 Socket
- 1 Ratchet
- 1 Torque Wrench
- 1 8MM Allen Key
- 1 Ratchet 6" Extension

STEP 1

Remove the two ExtendMySeat brackets from the package and locate the four black 3/8 bolts provided.

STEP 2

Use a 16 socket to remove the factory bolts in the front seat of the car then slide your seat all the way forward.





STEP 3

Move to the backseat. Locate and remove the seat caps and two rear factory bolts.





STEP 4

Move your seat all the way back to lift the front of your seat up so you can slide the brackets under the seat.

STEP 5

Lay down the two ExtendMySeat black brackets under the seat so the four factory holes align.

STEP 6

Start by tightening the rear factory hole with the factory bolt (closest to the outside of the car) then move to the rear inside and continue in a counter-clockwise pattern. You will need to slightly tighten all of the factory bolts into the factory hole locations.

STEP 6 cont.





STEP 7

Line up the seat to the new ExtendMySeat hole locations. Slightly tighten the two front seat "feet" into the new ExtendMySeat hole locations using the ExtendMySeat bolts.





STEP 8

Complete the installation by securing the eight bolts (four factory and four ExtendMySeat). Check to make sure all eight bolts are now tight and secure.



STEP 9

Place the front seat cap back onto the ExtendMySeat brackets. Place the large bolt sleeve down, then the seat cap and secure.

STEP 10

Complete the installation by securing all eight bolts (four factory and four ExtendMySeat). Check to make sure all eight bolts are tight and secure.

STEP 11

Test the seat by sliding it back and forth. You are complete.

MORE INFORMATION

To view a video on installation, please visit extendmyseat.com/ install-guides/

EXTENDMYSEAT.COM 3186-H Airway Avenue Costa Mesa, California 92626