

Honda Odyssey

Installation Guide: Thank you for purchasing ExtendMySeat (EMS) brackets. Please follow the directions carefully.

Inventory in Box:

- 3 ExtendMySeat brackets
- 4 Black 3/8" stainless bolts and nuts

What you will need for assembly:

1- Socket wrench and 6" extension

1- Socket Set

Step 1- Remove the 3 Black ExtendMySeat brackets from the packaging.

<u>Step 2-</u> Go to your vehicle with a socket wrench and the sockets, eye protection and your keys. Remember to turn off your cabin lights.

<u>Step 3-</u> Go to the front seat and remove the front seat plastic caps (it helps to remove by pulling away from the seat). Take your socket wrench and loosen the 2 front factory bolts.





<u>Step 4-</u> Go to the rear seat. Remove the 1 plastic guard to locate the 2-rear factory bolts. Now remove the rear bolts. The factory seat is now unsecure.



Now un-bolt the front factory seat foot from the seat chair on the front inner locations (2 bolts). The 2 bolts are under the factory foot.

<u>Step 5-</u> Bolt the EMS replacement foot back onto the factory seat base. You will not need the factory-removed foot. Please save in case you sell your vehicle.



<u>Step 6-</u> Bolt the outer factory foot to the smaller EMS bracket.

Do Not bolt the front brackets back to the floorboard until you have installed the rear bracket.



<u>Step 7-</u> Begin securing the rear EMS bracket to the vehicle. Start with the rear outer. Connect the large EMS bracket to the outer rear factory hole. Repeat on rear inner. You will need a flat wrench to secure the bolts.



<u>Step 8-</u> Go back to the front. You will need to cut a section of the carpet, which is under the new seat location. You will need to cut back 3.75" and 2.5" inward.

After you cut the carpet on both the inner and outer front locations; the chair can be secured to the floorboard.



<u>Step 10-</u> After you secure the front bolts back to the floorboard; you can place the removed carpet back over the factory bolts. Now go the rear and connect the factory seat to the EMS brackets.



Step 11- Now that the front is secure; go to the rear and secure the rear locations. Replace seat caps and enjoy.